



Royal Baths Manufacturing Co., Ltd.

14635 Chrisman Road

Houston, Texas 77039

(281)442-3400

1-800-826-0074

Trouble Shooting Guide

If your motor does not work:

- Plug not plugged into outlet - plug in
 - No switch or timer to control plug outlet - need switch
 - G.F.I. breaker either at bathroom or main panel has been tripped - reset
 - Breaker at panel has tripped at main power panel - reset
 - Something has sucked into impeller through suction line and has clogged the impeller - disconnect suction line from pump, remove obstruction. Replace suction line to pump and check breakers.
 - Plug not provided for pump - have builder provide plug
 - No line run from breaker panel to switch - have builder provide line
 - No breaker in the breaker panel - have builder or electrician provide breaker
-
- Water slow filling in tub - plumber problem
 - Water drains too slowly - plumber problem
 - Jets are missing - contact builder or furnish
 - Drill faucet holes - need a 3/8" drill (using 1 1/4" carbide tipped hole saw with 1/4" or 3/8" pilot bit)

CARE OF ROYAL BATHS PRODUCTS

For cleaning of the surface of Royal Baths Product:

Clear liquid cleaners, such as TopJob, Lysol, Glass Plus, or Mr. Clean, for cleaning and bringing luster to the surface.

For removing Latex paint - use a 50/50 solution of rubbing alcohol and water, or use a soft wooden stick (frozen treat type) to gently scrape paint off. Make sure not to gouge the surface.

For cleaning of system:

Once a month use one cup of chlorine bleach or vinegar to run through your system. Run it this way for twenty minutes with hot water, empty water, and then run the system for twenty minutes with clean, cold water.

For repair of the surface of your Royal Baths Product:

Light scratches - use an auto polishing compound or white paste toothpaste, such as Colgate or Crest. Do not use the gel type. Once applied, gently rub the paste into the surface, and then wash off with a soft cloth and water.

To clean the velcro on the Royal Signature Series:

Velcro can be cleaned with warm soapy water. Make sure NOT to saturate the velcro. Only clean the problem areas.

This literature supercedes all previously
printed material from Royal Baths Manufacturing Co